

1. Preparation Video 00.00-18.01

- Disassembly Original bottom protection.

Aluminum plates and black side plates/ Black Original protection product.

- Remove the 5 original brackets and mud flaps (See video 09.26-10.44)
- Keep all removed mounting materials!

2. Assembling Rocksliders (Video 11.15-22.18)

- Measure out rocksliders for placement (Video 11.15-15.25)

Sizes 51 cm, 73 cm, 91 cm 149 cm

- Remove the bolts in the sills
- Mark the holes. Distance from inside is 3cm
- Drill 3 holes 38mm (pre-drill if necessary, see video)
- 4th hole clearing/cut out
- Put plugs back in the sills Video 15.58-16.28
- Remove bolt from the tank plate Video 17.45-18.02
- Assemble Rockslider using 2 jacks (jack protection)
- Jack the rockslider up and check that the connection to the pipes is correct video 18.51-18.55
- Mount the bolts 5x bolt M10x100 front holes M10x120 Video 19.05-20.31 * advice to grease bolts with copper grease/ceramic grease
- Inside 4x bolts M10x40
- Tighten everything without tank protection (tighten everything later with tank protection)
- Repeat for other side.

3. Placement Diff protection Video 24.04-30.24

- Release the rear exhaust from the rubbers on both sides.
- Slide diff protection plate in place. (trial placement)
- Loosen heat shield bolts
- Remove heat shield
- Detach/remove clip
- Jack up to support Diff

- Loosen 2x bolts inside diff (see video!) Video 24.53- 26.44
- Remove jack
- Test the diff protection plate
- Replace bolts
- Replace jack
- Install and tighten all bolts
- * Back is M10x30 Front Original
- Replace exhaust/muffler

4. Tank protection plates Video 30.24- 47.40

- Place the tank protector under the tank
- Draw the heat shield on both the left and right
- Remove the heat shield
- Cut away the remaining parts so that the tank protectors can be mounted
- Replace the heat shield
- Place the mounting brackets (do not tighten yet)
- Tap the front brackets M10
- Place the tank protection plates
- And tighten all bolts M10

Repeat for other side.

Note: That the tank protection plates are clear of the exhaust

5. Place center and front protection plates Video 47.40-57.40

- Start by placing the center protection plate under the car. (for position use the front bolt holes)
- Mark the heat shield and remove the marked parts
- Mark mounting center bracket on rockslider (tip: use tape) Video 48.54-49.41
- Remove center protection plate
- Install the center bracket and remove the heat shield as shown
- Check that all bolts are in the correct position at the large center protection plate before mounting
- Tighten all bolts
- Place the front protection plate under the car.